

COMET SYSTEM

www.cometsystem.com

P2520 two-channel current loop converter

USER GUIDE

© Copyright: COMET SYSTEM, s.r.o.

Is prohibited to copy and make any changes in this manual, without explicit agreement of company COMET SYSTEM, s.r.o. All rights reserved.

COMET SYSTEM, s.r.o. makes constant development and improvement of their products. Manufacturer reserves the right to make technical changes to the device without previous notice. Misprints reserved.

Manufacturer is not responsible for damages caused by using the device in conflict with this manual. To damages caused by using the device in conflict with this manual may not be provided free repairs during the warranty period.

Contact the manufacturer of this device:

COMET SYSTEM, s.r.o.
Bezrucova 2901
756 61 Roznov pod Radhostem
Czech Republic
www.cometsystem.com

Revision history

This manual describes devices with latest firmware version according to table below. Older version of manual can be obtained from a technical support.

Document version	Date of issue	Firmware version	Note
IE-SNC-P2520-01	2014-01-14	7-5-0-x	Initial revision of manual.
IE-SNC-P2520-02	2021-04-07	7-5-1-0	Added DNS support for SOAP and email Added chapter with XML and JSON description Added support for SNMP sysLocation New revision of texts and images
IE-SNC-P2520-03	2022-07-01	unchanged	change of case material

Table of contents

Introduction.....	4
General safety rules	4
Device description and important notices.....	5
Getting started.....	6
What is needed for operation	6
Mounting the device.....	6
Device settings	7
Device setup	9
Setup using web interface.....	9
Backup.....	16
Factory defaults.....	16
Communication protocols	19
Website	19
SMTP – sending e-mails.....	19
SNMP	19
Modbus TCP	21
SOAP.....	22
XML and JSON.....	23
Syslog	24
SNTP.....	24
Troubleshooting.....	25
I forgot the device IP address.....	25
I cannot connect to the device	25
Error codes	26
I forgot the password for setup.....	26
Factory defaults.....	26
Technical specifications	27
Dimensions	27
Basic parameters	27
Operating terms	29
End of operation	29
Technical support and service	29
Preventive maintenance.....	29

Introduction

This chapter provides basic information about device. Before starting, please read this manual carefully.

P2520 two-channel current loop converter is designed to connect sensors with output 0-20 mA or 4-20 mA into Ethernet network. Current can be recalculated to physical value measured by the connected sensor. Sensors can be powered directly from the P2520 Converter. P2520 have two current inputs. These inputs are not galvanically isolated.

General safety rules

The following summary is used to reduce the risk of injury or damage the device. To prevent injury, please follow instructions in this manual carefully.



The device can be installed and repaired by a qualified person only. The device contains no serviceable parts inside standard means.

Do not use the device, if it does not work correctly. Let check device by the qualified service person if you think that is not working properly.

It is forbidden to use the device without the cover. Inside the device can be a dangerous voltage and may be risk of electric shock.

Appropriate power supply adapter according to manufacturer specifications and approved according to relevant standards may to be used only. Please make sure, that the adapter does not have damaged cables or covers.

Connect the device to network parts approved according to relevant standards only.

Connect and disconnect the device properly. Do not connect or disconnect Ethernet cable or current inputs when the device is powered.

Do not short-circuit power supply terminals +U1 and +U2 to the GND terminals.

The device may be installed in prescribed areas only. Never expose the device to higher or lower temperatures than is allowed. Protect device from dripping or splashing water and do not use in areas with condensation.

Do not use device in potentially explosive environments.

Do not stress the device mechanically.

Device description and important notices

This chapter contains information about basic features and device functional safety.

Values from the device can be read using an Ethernet connection. The following formats are supported:

- Web pages with XML and JSON files
- Modbus TCP protocol
- SNMPv1 protocol
- SOAP protocol

The device can also be used to check measured values and if the limit is exceeded, device sends warning messages. Possible ways to sending warning messages:

- Sending e-mails up to 3 e-mail addresses
- Sending SNMP traps up to 3 configurable IP addresses
- Displaying the alarm status on web page
- Sending messages to Syslog server

The device setup can be made by the web interface. Latest firmware version can be obtained from the technical support. Do not upload to your device firmware which is not designed for it. Unsupported firmware can damage your device.



Reliability of warning messages delivering (e-mail, trap, syslog), depends on actual availability of necessary network services. The device should not be used for critical applications, where malfunction could cause to injury or loss of human life. For highly reliable systems, redundancy is essential. For additional information please see standard IEC 61508.



Never connect the device directly to the Internet. If it is necessary connect the device to the Internet, properly configured firewall must be used. For a remote connection to the device should be VPN or similar secured access used only.

Getting started

Here you can find information necessary to put newly purchased equipment to operation. Read information about current loop connection carefully.

What is needed for operation

To install the unit, you need to the following equipment. Please check if it is available before installation.

- P2520 current loop converter
- screwdriver for removing cover
- power supply – according to specification (commonly DC 24 V/1.0 A)
- RJ45 LAN connection with appropriate cable
- free IP address in your network
- sensor(s) with current loop output (4-20 mA or 0-20 mA)


Mounting the device

- check if the equipment from the previous chapter is available
- install the latest version of TSensor software. This software will help you find device on network and to change IP address of the device. Device configuration is made using web interface. TSensor software can be downloaded from the manufacturer's website.
- contact your network administrator to obtain following information for the connection to the network:


IP address:	_____.	_____.	_____.	_____.
Gateway:	_____.	_____.	_____.	_____.
Netmask:	_____.	_____.	_____.	_____.
DNS IP address:	_____.	_____.	_____.	_____.

- check if there is no IP address conflict when you connect the device into network for the first time. The device has from factory set the IP address to **192.168.1.213**. This address must be changed according to information from the previous point. When you install several new devices, connect them to the network one after another.
- remove device cover, connect current loops, and power supply terminals according to image below. **Inputs channels on the device are not galvanically isolated. Power supply is not isolated from inputs as well!** Device is isolated from communication line side only. Carefully consider how connect sensor with current output into your P2520.
- close device cover
- connect the Ethernet connector
- power on the power supply adapter
- LEDs on LAN connector should blink after connecting the power

P2520 inputs schematic:




Sensor connection example:




Device settings


- run configuration software TSensor on your PC
- switch to an **Ethernet** communication interface
- press button **Find device...**



- the window shows all available devices on your network



- click to **Change IP** to set new address according to network administrator instructions. If your device is not listed, then click **Help! My device wasn't found!** Then follow the instructions. MAC address is on product label. The device is factory set to IP **192.168.1.213**.




- gateway may not be entered if you want to use the device in local network only. If you set the same IP address which is already used, the device will not work correctly due to IP address collision. If the device detects a collision of IP address, then reboot is performed automatically.
- after changing IP address device is restarted and new IP address is assigned. Restart of the device takes up to 10 seconds.
- connect to device using TSensor software. TSensor software will forward you to web interface. On the web interface you can set your device according to requirements.

Device setup

This chapter describes basic device configuration. There is a description of settings using web interface.

Setup using web interface

Web interface can be managed by the web browser. Main page will be shown when you insert device address into address bar of your web browser. There you find actual measured values. Page with history graphs is shown when you click to tile with actual values. Access to device setup is possible via tile **Settings**.



General

Device name can be changed using item **Device name**. Measured values are stored into memory according to **History storage interval** field. After changing of this interval all history values will be cleared. Be aware that content of memory for history values is not preserved after device restart or power lost. Changes must be confirmed by **Apply settings** button.

The screenshot shows the 'Settings' menu with 'General' selected. The 'General' section is highlighted in the left sidebar. The main content area shows the 'General device settings' page. It includes a 'Back' button, a 'Device name' field with the value 'My device', and a 'History storage interval' dropdown menu set to '2 Sec'. There are 'Apply settings' and 'Cancel changes' buttons at the bottom right.

Network

Network parameters can be obtained automatically from DHCP server using option **Obtain an IP address automatically**. Static IP address is configurable via field **IP address**. It is not necessary setup **Default gateway** while is device used inside one subnet only. **DNS server IP** is used to resolving addresses for SOAP protocol or communication with SMTP (mail) server. Option **Standard subnet mask** sets network mask automatically according to A, B or C network class. **Subnet mask** field must be set manually when network with non-standard range is used. **Periodic restart interval** enables to restart device after selected time since device start.

The screenshot shows the 'Settings' menu with 'Network' selected. The 'Network' section is highlighted in the left sidebar. The main content area shows the 'Basic settings of the network interface' page. It includes a 'Back' button, a checkbox for 'Obtain an IP address automatically', and fields for 'IP address' (192.168.1.42), 'Default gateway' (192.168.1.1), 'DNS server IP' (192.168.1.1), 'Standard subnet mask' (checkbox), 'Subnet mask' (255.255.255.0), and a 'Periodic restart interval' dropdown menu set to 'Off'. There are 'Apply settings' and 'Cancel changes' buttons at the bottom right.

Alarm limits

For each measurement channel is possible to set upper and lower limits, time-delay for alarm activation (0 – 30000 s) and hysteresis for alarm clearing.

Back
Exit to main menu

Settings Alarm limits

Configuration of the alarm limits. The safe range is between high and low limit. Alarm condition occurs while measured value is out of the safe range for selected time delay. Alarm is cleared if measured value returns to safe range with hysteresis.

Channel 1 limits
Channel name: Humidity
Current value: 38.59 %RH

High limit	Low limit	Hysteresis	Time delay [sec]
30.00000	15.00000	10.00000	60

Channel 2 limits
Channel name: Temperature
Current value: 25.65 C

High limit	Low limit	Hysteresis	Time delay [sec]
28.00000	18.50000	1.00000	30

Apply settings
Cancel changes

General
General device settings

Network
Basic settings of the network interface


Alarm limits
Configuration of the alarm limits

Channels
General settings of the channels

SOAP protocol
Setup SOAP protocol for database system

Email
Alarm emails configuration

Example of setting the limit to the upper alarm limit:



In Point 1 the measured value exceeded the limit. From this time, the time-delay is counting. Because at point 2 the value dropped below the limit value before the time delay expired, alarm was not set.

In Point 3 the value has risen over limit again. During the time-delay the value does not drop below the set limit, and therefore was in Point 4 caused alarm. At this moment were sent e-mails, traps and set alarm flag on website, SNMP and Modbus.

The alarm lasted up to Point 5, when the measured value dropped below the set hysteresis (high limit – hysteresis). At this moment was active alarm cleared and e-mail send.

When alarm occurs, alarm messages will be sent. In case of power failure or device reset (e.g. changing the configuration) will new alarm state evaluated and new alarm messages will be send.

Channels

Channel can be enabled or disabled for measuring using checkbox **Enabled**. Channel can be renamed, and unit of channel can be changed. Measured current is recalculated to physical representation according to selected linear equation. Number of decimal places is selectable. All changes must be confirmed using **Apply settings** button. History values are cleared after changing of channel settings.

Back
Exit to main menu

Settings Channels

General
General device settings

Network
Basic settings of the network interface

Alarm limits
Configuration of the alarm limits

Channels
General settings of the channels

SOAP protocol
Setup SOAP protocol for database system

Email
Alarm emails configuration

Protocols
Syslog and ModbusTCP protocol settings

SNMP
SNMPv1 protocol and SNMP Traps

Time
Synchronization with NTP server

General settings of the channels. For each channel is possible to set name and unit. Measured current is recalculated to output values according settings. Output value is rounded according selected number of decimal places.

Channel 1
Measured current: 10.862 [mA]
Calculated value (approximately): 42.89 %RH

☒ Enabled Humidity %RH

Current 4.00000 [mA] will be shown as 0.00000

Current 20.00000 [mA] will be shown as 100.00000

Number of decimal places 2

Channel 2
Measured current: 11.286 [mA]
Calculated value (approximately): 20.09 C

☒ Enabled Temperature C

Current 4.00000 [mA] will be shown as -30.00000

Current 20.00000 [mA] will be shown as 80.00000

Number of decimal places 2

Apply settings Cancel changes

SOAP protocol

SOAP protocol can be enabled by option **SOAP protocol enabled**. Address of the destination http server is configurable via **SOAP server address** filed. For setup of destination server port can be used option **SOAP server port**. Device sends SOAP message according selected **Sending interval**. Option **Send SOAP message when alarm occurs** sends message when an alarm on channel occurs or alarm is cleared. These SOAP messages are sent asynchronously to selected interval.

SOAP protocol is used for data transfers into COMET Cloud or COMET Database. Detail description of setup you find at documentation for each data acquisition system.

Back
Exit to main menu

Settings SOAP

General
General device settings

Network
Basic settings of the network interface

Alarm limits
Configuration of the alarm limits

Channels
General settings of the channels

SOAP protocol
Setup SOAP protocol for database system

Email
Alarm emails configuration

Setup SOAP protocol for database system. Current measured values are sent as XML files. For more information please read the user guide for database system.

SOAP protocol enabled ☒

SOAP server address http://wsi.cometsystem.cloud/

SOAP server port 80

Sending interval 5 Min

Send SOAP message when alarm occurs ☒

Apply settings Cancel changes

Email

Email sending enabled option allows email features. It is necessary set address of the SMTP server into **SMTP server address** field. Default port of the SMTP server can be changed using item **SMTP server port**. SMTP authentication can be enabled using **SMTP authentication** option. When authentication is enabled **Username** and **Password** must be set.

For successfully email sending it is necessary insert **Email sender address**. This address is usually same as username of the SMTP authentication. Into fields **Recipient 1** to **Recipient 3** it is possible set address of email recipients. Option **Short email** enable sending emails in short format. This format is usable when you need to forward emails into SMS messages.

When option **Alarm email repeat sending interval** is enabled and there is active alarm on channel, then emails with actual values are sent repeatedly. **Info email sending interval** option enables sending emails at selected time interval. CSV history file can be sent together with the repeat/info emails. This feature can be enabled by **Alarm and Info emails attachment** option.

It is possible to test email function using button **Apply and test**. This button saves a new setting and send a testing email immediately.

Settings		Email
Back Exit to main menu		
General General device settings	Configuration of the alarm emails. Device can send warning email when alarm on measured channel occurs. Email is also sent when alarm condition is cleared.	
Network Basic settings of the network interface	Email sending enabled <input checked="" type="checkbox"/>	
Alarm limits Configuration of the alarm limits	SMTP server configuration For proper email sending it is necessary to setup connection to your SMTP server. SMTP authentication can be used if needed. For information about SMTP server settings please contact your network administrator or ISP.	
Channels General settings of the channels	SMTP server address <input type="text" value="smtp.seznam.cz"/>	
SOAP protocol Setup SOAP protocol for database system	SMTP server port <input type="text" value="25"/>	
Email Alarm emails configuration	SMTP authentication <input checked="" type="checkbox"/>	
Protocols Syslog and ModbusTCP protocol settings	Username <input type="text" value="user@email.cz"/>	
SNMP SNMPv1 protocol and SNMP Traps	Password <input type="password" value="....."/>	
Time Synchronization with NTP server	Email configuration Setup up to three address for email recipients. Sender address is usually the same as the username of the SMTP authentication.	
WWW and Security Web server and Security configuration	Email sender address <input type="text" value="user@email.cz"/>	
Backup Save or restore configuration	Recipient 1 <input type="text" value="test@example.com"/>	
Maintenance Factory defaults, info, etc.	Recipient 2 <input type="text"/>	
	Recipient 3 <input type="text"/>	
	Short email <input type="checkbox"/>	
	Alarm email repeat sending interval <input type="text" value="1 Hour"/>	
	Info email sending interval <input type="text" value="1 Day"/>	
	Alarm and Info emails attachment <input type="text" value="Export_comma.csv"/>	
	<input type="button" value="Apply settings"/> <input type="button" value="Apply and test"/> <input type="button" value="Cancel changes"/>	

Modbus a Syslog protocols

ModbusTCP and Syslog protocol settings are configurable via menu **Protocols**. Modbus server is enabled by default. Deactivation is possible via **Modbus server enabled** option. Modbus port can be changed via **Modbus port** field. Syslog protocol can be enabled using item **Syslog enabled**. Syslog messages are sent to IP address of the Syslog server - field **Syslog server IP address**.

Back
Exit to main menu

Settings Protocols

General
General device settings

Network
Basic settings of the network interface

Alarm limits
Configuration of the alarm limits

Channels
General settings of the channels

SOAP protocol
Setup SOAP protocol for database system

Email
Alarm emails configuration

Protocols
Syslog and ModbusTCP protocol settings

ModbusTCP protocol
Configuration of the ModbusTCP protocol. Current measured values can be read using ModbusTCP protocol. Modbus registers are described inside the user manual.

Modbus server enabled ☒

Modbus port

Syslog protocol
Configuration of the Syslog protocol. Alarm messages can be sent to the Syslog server using UDP protocol.

Syslog enabled ☒

Syslog server IP address

Apply settings **Cancel changes**

SNMP

For reading values via SNMP it is necessary to know password - **SNMP read community**. SNMP Trap can be delivered up to three IP address - **IP address of the Trap recipient**. SNMP Traps are sent at alarm or error state on the channel. Trap feature can be enabled by option **Trap enabled**.

Back
Exit to main menu

Settings SNMP

General
General device settings

Protocols
Syslog and ModbusTCP protocol settings

SNMP
SNMPv1 protocol and SNMP Traps

Time
Synchronization with NTP server

WWW and Security
Web server and Security configuration

Backup
Save or restore configuration

Maintenance
Factory defaults, info, etc.

Configuration of the SNMPv1 protocol and SNMP Traps. Current measured values can be read using SNMP protocol. When alarm on channel occurs a warning message (Trap) can be sent to selected IP addresses.

SNMP read community

System location

Trap enabled ☒

IP address of the Trap recipient 1

IP address of the Trap recipient 2

IP address of the Trap recipient 3

Apply settings **Cancel changes**

Time

Time synchronization with SNTP server can be enabled by **Time synchronization enabled** option. IP address of the SNTP is necessary to set into **SNTP server IP address** item. SNTP time is synchronized at UTC format, and due to be necessary set corresponding time offset – **GMT offset [min]**. Time is synchronized every 24 hours by default. Option **NTP synchronization every hour** decreases this synchronization interval to one hour.

Back
Exit to main menu

Settings Time

General
General device settings

SNMP
SNMPv1 protocol and SNMP Traps

Time
Synchronization with NTP server

WWW and Security
Web server and Security configuration

Backup
Save or restore configuration

Maintenance
Factory defaults, info, etc.

Time can be synchronized according the SNTP server. To correct time is necessary set GMT offset of your time zone. Time synchronisation is required for timestamps inside CSV files.

Time synchronised with server yes (at 06:34:36 2021-04-03)

Time synchronization enabled ☒

SNTP server IP address

GMT offset [min]

NTP synchronization every hour ☐

Apply settings
Cancel changes

WWW and security

Device security features can be enabled by the **Security enabled** option. When security is enabled it is necessary to set administrator password. This password will be required for device settings. When secured access is required even to actual values reading it is possible to enable **User account only for viewing**. Port of the www server can be changed from the default value 80 using field **WWW port**. Web pages with actual values are refreshed according to **Web refresh interval** field.

Back
Exit to main menu

Settings WWW and Security

General
General device settings

Network
Basic settings of the network interface

Alarm limits
Configuration of the alarm limits

Channels
General settings of the channels

SOAP protocol
Setup SOAP protocol for database system

Email
Alarm emails configuration

Protocols
Syslog and ModbusTCP protocol settings

SNMP
SNMPv1 protocol and SNMP Traps

Time
Synchronization with NTP server

WWW and Security
Web server and Security configuration

Backup
Save or restore configuration

Maintenance
Factory defaults, info, etc.

Security
Configuration of the secure access to the device. Administrator password must be inserted if security is enabled. Administrator password is used for device configuration. User password is used only for measured values viewing.

Security enabled ☒

Administrator username

Administrator password

Confirm Administrator password

User account only for viewing enabled ☒

User username

User password

Confirm User password

Web server
Configuration of the embedded web server. Web server can be disabled by TSensor software.

Web server enabled ☒

WWW port

Web refresh interval

Apply settings
Cancel changes

Backup

Device configuration may to be saved into file. This file can be used to restoring configuration or cloning configuration between devices. Configuration can be cloned between same device models only. It may to be restored all device settings with exception network settings, www and security settings.

Factory defaults

Factory defaults button set the device into factory configuration. Network parameters (IP address, Subnet mask, DNS, Gateway) are left without changes.

Back
Exit to main menu

Settings

Maintenance

General
General device settings

Network
Basic settings of the network interface

Alarm limits
Configuration of the alarm limits

Channels
General settings of the channels

SOAP protocol
Setup SOAP protocol for database system

Email
Alarm emails configuration

Protocols
Syslog and ModbusTCP protocol settings

SNMP
SNMPv1 protocol and SNMP Traps

Time
Synchronization with NTP server

WWW and Security
Web server and Security configuration

Backup
Save or restore configuration

Maintenance
Factory defaults, info, etc.

Info
Basic informations about device. Find more detailed information on the diagnostic page. Please send the diagnostic file together with request to support.

Device type	P2520
Serial number	15940001
MAC address	00-20-4A-EA-4C-EA
Firmware version	7-5-1-0.0795 / 1.20
Build firmware notice	Leopard cat
Device uptime	1 h, 29 min, 2 sec
Diagnostic file	192.168.1.42/diag.log

Restart
Device will be restarted after dialog confirmation. All history values are cleared after restart. Restarting of the device will take a few seconds.

Restart device

Factory defaults
Factory defaults button restores device to factory settings. Network parameters like a IP address, subnet mask and gateway IP will not be changed.

Factory defaults

Network parameters are changed while you press button inside the device. For more information, please read chapter *Factory defaults*.

Factory parameters settings:

Parameter	Value
SMTP server address	example.com
SMTP server port	25
Alarm email repeat sending interval	off
Info email sending interval	off
Alarm and Info emails attachment	off
Recipients addresses	cleared
Email sender address	sensor@websensor.net
SMTP authentication	off
SMTP user/SMTP password	cleared
Email sending enabled	off
IP addresses SNMP traps recipients	0.0.0.0
SNMP read community	public
Sending SNMP Trap	off
SNMP System location	cleared
Web refresh interval [sec]	10
Web server enabled	yes
WWW port	80
Security	off
Administrator password	cleared
User password	cleared
Modbus port	502
Modbus server enabled	yes
History storage interval [sec]	60
SOAP server address	cleared
SOAP server port	80
SOAP sending interval [sec]	60
Send SOAP message when alarm occurs	yes
SOAP protocol enabled	off
Syslog server IP address	0.0.0.0
Syslog protocol enabled	off
SNTP server IP address	0.0.0.0
GMT offset [min]	0
NTP synchronization every hour	off
Time synchronization enabled	off
MTU size	1400
Periodic restart interval	off
Demo mode	off
Turn on all channels	yes
High limit	15.0
Low limit	10.0
Hysteresis – hysteresis for alarm clearing	1.0
Time delay – time-delay of alarm activation [sec]	30
Unit on the channel	mA
Channel name	Channel X (where X is 1 and 2)
Current low	4.0
Current high	20.0
Readings value low	4.0
Readings value high	20.0

Number of decimal places	2
Device name	Current Loop Converter

Communication protocols

Short introduction to communication protocols of the device. To use some communication protocols is necessary software, which can use the protocol. This software is not included.

Website

The device supports displaying of measured values, history graphs and configuration using web browser. History graphs are based on HTML5 canvas. Web browser must support this feature for proper function of graphs. Firefox, Opera, Chrome, or Edge can be used. If the device has IP address **192.168.1.213** type into your browser **http://192.168.1.213**. Actual measured values can be obtained using file **values.xml** or using **values.json**.

Values from history can be exported in CSV format. History storage interval can be set using web interface. History is erased after every reboot of the device. Reboot of the device is performed when the power supply is disconnected and after some configuration changes.

SMTP – sending e-mails

When measured values are over the set limits, the device allows send e-mail to a maximum of 3 addresses. E-mail is sent when alarm condition on the channel is cleared or a measuring error occurs. It is possible to set repeat interval for email sending. For correct sending of e-mails it is necessary to set address of SMTP server. SMTP authentication is supported but SSL/TLS not. Standard SMTP port 25 is used by default. SMTP port can be changed. Contact your network administrator to obtain configuration parameters of your SMTP server. E-mail sent by the device cannot be answered.

SNMP

Using SNMP protocol, you can read actual measured values, alarm status. Writing via SNMP protocol is not supported. It is supported **SNMPv1** protocol version only. SNMP used **UDP port 161**. OID keys description can be found in the MIB table, which can be obtained from

device website or from your distributor. The password for reading is factory set to **public**.
OID keys:

OID	Description	Type
.1.3.6.1.4.1.22626.1.6.1	Device information	
.1.3.6.1.4.1.22626.1.6.1.1.0	Device name	String
.1.3.6.1.4.1.22626.1.6.1.2.0	Serial number	String
.1.3.6.1.4.1.22626.1.6.1.3.0	Device type	Integer
.1.3.6.1.4.1.22626.1.6.2.ch	Measured value (where ch is channel number)	
.1.3.6.1.4.1.22626.1.6.2.ch.1.0	Channel name	String
.1.3.6.1.4.1.22626.1.6.2.ch.2.0	Unit	String
.1.3.6.1.4.1.22626.1.6.2.ch.3.0	Value	String
.1.3.6.1.4.1.22626.1.6.2.ch.4.0	Actual value – 16bit (12dgrC=12)	Integer
.1.3.6.1.4.1.22626.1.6.2.ch.5.0	Actual value – 16bit (12.5dgrC=125)	Int*10
.1.3.6.1.4.1.22626.1.6.2.ch.6.0	Actual value – 16bit (12.53dgrC=1253)	Int*100
.1.3.6.1.4.1.22626.1.6.2.ch.7.0	Actual value – 16bit (12dgrC=12)	Integer
.1.3.6.1.4.1.22626.1.6.2.ch.8.0	Actual value – 32bit (12.5dgrC=125)	Int*10
.1.3.6.1.4.1.22626.1.6.2.ch.9.0	Actual value – 32bit (12.53dgrC=1253)	Int*100
.1.3.6.1.4.1.22626.1.6.2.ch.10.0	Actual current [mA]	String
.1.3.6.1.4.1.22626.1.6.2.ch.11.0	Actual current [uA] (120uA=120)	Integer
.1.3.6.1.4.1.22626.1.6.2.ch.12.0	Alarm on channel (0, 1, 2)	Integer
.1.3.6.1.4.1.22626.1.6.2.ch.13.0	Alarm on channel (none, high, low)	String
.1.3.6.1.4.1.22626.1.6.3.1.0	SNMP Trap text	String

When alarm occurred a warning messages (trap) can be sent to selected IP addresses. Addresses can be set using web interface. Traps are sent via **UDP** protocol on **port 162**. The device can send following traps:

Trap	Description	
0/0	Reset of the device	
1/0	Settings was changed	
6/0	Testing Trap	
6/1	NTP synchronization error	
6/2	E-mail sending error	SMTP server login error
6/3		SMTP authentication error
6/4		Some error occurred during SMTP communication
6/5		TCP connection to server cannot be opened
6/6		DNS error
6/7	SOAP message sending error	SOAP file not found inside web memory
6/8		DNS error or MAC address cannot be obtained
6/9		TCP connection to server cannot be opened
6/10		Wrong response code from the SOAP server
6/11, 6/12	Upper alarm on channel	
6/21, 6/22	Lower alarm on channel	
6/31, 6/32	Clearing alarm on channel	
6/41, 6/42	Measuring error	

Modbus TCP

Device supports Modbus protocol for communication with SCADA systems. Device use Modbus TCP protocol. **TCP port** is set to **502** by default. Port can be changed using web interface. Only two Modbus clients can be connected to device at one moment. Modbus device address (Unit Identifier) can be arbitrary. Modbus write command is not supported. Specification and description of the Modbus protocol is free to download on: www.modbus.org.

Supported Modbus commands (functions):

Command	Code	Description
Read Holding Register (s)	0x03	Read 16b register(s)
Read Input Register(s)	0x04	Read 16b register(s)

Modbus device registers. Address could be by 1 higher, depending on type used communication library:

Address [DEC]	Address [HEX]	Description	Type
39970	0x9C22	1st two digits from serial number	BCD
39971	0x9C23	2nd two digits from serial number	BCD
39972	0x9C24	3rd two digits from serial number	BCD
39973	0x9C25	4th two digits from serial number	BCD
39974	0x9C26	Device type	Int16b
39975, 39976	0x9C27, 0x9C28	Current on channel [uA]	Int16b
39977 – 39978	0x9C29 – 0x9C2A	Actual value channel1	Float32b
39979 – 39980	0x9C2B – 0x9C2C	Actual value channel2	
39981, 39982	0x9C2D, 0x9C2E	Actual value	Int16b
39983, 39984	0x9C2F, 0x9C30	Actual value	Int16b*10
39985, 39986	0x9C31, 0x9C32	Actual value	Int16b*100
39987, 39988	0x9C33, 0x9C34	Unit on the channel	Ascii
39989, 39990	0x9C35, 0x9C36	Channel alarm state	uInt16b
39991 – 39999	0x9C37 – 0x9C3F	Unused	n/a
40000	0x9C40	Channel 1 actual value	Int16b*10
40001	0x9C41	Channel 1 alarm status	Ascii
40002	0x9C42	Channel 1 current [uA]	Int16b*10
40003 – 40004	0x9C43 – 0x9C44	Channel 1 Actual value	Int32b*100
40005	0x9C45	Unused	n/a
40006	0x9C46	Channel 2 actual value	Int*10
40007	0x9C47	Channel 2 alarm status	Ascii
40008	0x9C48	Channel 2 current [uA]	Int16b*10
40009 – 40010	0x9C49 – 0x9C4A	Channel 2 Actual value	Int32b*100
40011	0x9C4B	Unused	n/a

Description:

Int16b	registry range is -31999 to 32767, error value <= -32000
Int16b*10	registry is in format integer*10 – 16 bits, 12.5dgrC = 125, error value <= -32000
Int16b*100	registry is in format integer*100 – 16 bits, 12.53dgrC = 1253, error value <= -3200

Float32b	two Modbus registers containing IEEE754 float, lower 16bits first, error value = -inf
Int32b*100	two Modbus registers containing 32bit signed integer*100, 12.53dgrC = 1253, lower 16bits first, error value <= -320000000
Ascii	two ASCII character in register
BCD	registry is coded as BCD
n/a	item is not defined, should be read

SOAP

The device allows you to send currently measured values via **SOAP v1.1** protocol. The device sends values in XML format to the web server. The advantage of this protocol is that communication is initialized by the device side. Due to it is not necessary use port forwarding. If the SOAP message cannot be delivered, warning message via SNMP Trap or Syslog protocol is sent. The file with the XSD schema can be downloaded from: <http://cometsystem.cz/schemas/soapP2520.xsd>. SOAP message example:

```
Host: 192.168.1.132
Content-Type: text/xml; charset=utf-8
Content-Length: 656
SOAPAction: "http://tempuri.org/InsertP2520Sample"

<?xml version="1.0" encoding="utf-8"?>
<soap:Envelope xmlns:soap="http://schemas.xmlsoap.org/soap/envelope/"
xmlns:xsi="http://www.w3.org/2001/XMLSchema-instance"
xmlns:xsd="http://www.w3.org/2001/XMLSchema">

  <soap:Body>
    <InsertP2520Sample xmlns="http://cometsystem.cz/schemas/soapP2520.xsd">

      <name>Current Loop Converter</name>
      <sn>11940986</sn>
      <tmr>60</tmr>
      <kind>4357</kind>

      <c1>
        <n>Channel 1</n>
        <v>3.25</v>
        <f>00005040</f>
        <u>mA</u>
        <a>no</a>
        <p>2</p>
        <e>1</e>
      </c1>

      <c2>
        <n>Channel 2</n>
        <v>18.00</v>
        <f>00009041</f>
        <u>mA</u>
        <a>no</a>
        <p>2</p>
        <e>0</e>
      </c2>

    </InsertP2520Sample>
  </soap:Body>
</soap:Envelope>
```

XML and JSON

Measured values can be read from http server by http GET requests. Values are available at two data formats - XML and JSON. Values can be obtained via files **values.xml** and **values.json**. Webserver needs to be enabled to be values available.

Example of values.xml file:

```
<root>

  <err>0</err>
  <devname>My device</devname>
  <devsn>13940001</devsn>
  <time>2021-04-06T07:48:44+01:00</time>
  <timeunix>1617695324</timeunix>
  <synch>1</synch>

  <ch1>
    <name>Humidity</name>
    <unit>%RH</unit>
    <aval>34.93</aval>
    <alarm>1</alarm>
  </ch1>

  <ch2>
    <name>Temperature</name>
    <unit>C</unit>
    <aval>22.31</aval>
    <alarm>0</alarm>
  </ch2>

</root>
```

Example of values.json file:

```
{
  "devname": "My device",
  "devsn": "13940001",
  "time": "07:58:32 2021-04-06",
  "timeunix": "1617695912",
  "synch": "1",

  "ch1":
  {
    "name": "Humidity",
    "unit": "%RH",
    "aval": "34.94",
    "alarm": 1
  },

  "ch2":
  {
    "name": "Temperature",
    "unit": "C",
    "aval": "22.49",
    "alarm": 0
  }
}
```

Syslog

The device allows sending text message to selected Syslog server. Events are send using **UDP** protocol on **port 514**. Syslog protocol implantation is according to RFC5424 and RFC5426. Events when Syslog messages are send:

Text	Event
Sensor - fw 7-5-x.x	Reset of the device
Settings changed	Settings was changed
NTP synchronization error	NTP synchronization error
Testing message	Test Syslog message
Email dns error	E-mail sending error
Email login error	
Email auth error	
Email some error	
Email socket error	
SOAP file not found	SOAP message sending error
SOAP dns error	
SOAP host error	
SOAP sock error	
SOAP delivery error	
High alarm CHx	Upper alarm on channel
Low alarm CHx	Lower alarm on channel
Clearing CHx	Clearing alarm on channel
Error CHx	Measuring error

SNTP

The device allows time synchronization with NTP (SNTP) server. SNMP protocol version 3.0 is supported (RFC1305). Time synchronization is made every 24 hours. Time synchronization every hour can be enabled. For time synchronization it is necessary set IP address to the SNTP server. It is also possible set GMT offset for correct time zone. Time is used in graphs and history CSV files. Maximum jitter between two synchronization of time is 90sec at 24 hours interval.

Troubleshooting

The chapter describes the common problems with P2520 and methods how to fix these problems. Please read this chapter before you will call technical support.

I forgot the device IP address

IP address is factory set to **192.168.1.213**. If you had changed it and forgot new IP address, run the TSensor software and press **Find device...** In the window are displayed all available devices.

I cannot connect to the device

In search window is only IP and MAC address displayed

Other details are marked **N/A**. This problem occurs if IP address of the device is set to another network (subnet).

Select the window **Find device** in TSensor software and press **Change IP address**. Follow the software instructions. To assign IP address automatically using DHCP server, set the device IP address to **0.0.0.0**.

Device IP address is not displayed in window Find device

In TSensor software menu press **Help! My device was not found!** in window **Find device**. Follow the software instructions. MAC address of the device can be found on the product label.

The device is not found even after manually setting MAC address

This problem occurs especially in cases when the IP address of the device belongs to another network and also Subnet mask or Gateway are incorrect.

In this case is DHCP server in the network necessary. In TSensor software press **Help! My device was not found!** in window **Find device**. As new IP address set **0.0.0.0**. Follow the software instructions. An alternative is to reset device to factory defaults using factory-defaults button.

Error codes

Table below describes common error codes from the device:

Error code	Description	How to resolve problem
n/a	Value is not available	Value n/a is shown a shortly after device restart. If the error code or n/a is displayed permanently, then channel is not enabled.
Error 1	Value can't be converted to string	Constants for recalculation are wrongly set, change them.
Error 2	Internal Error – communication	Please contact technical support.
Error 3	Register overflow	Measured value cannot be shown at register (16bit). Please use 32bit register or change constants for recalculation.
Error 4	Undocumented error	Please contact technical support.
Error 5	Internal Error – CRC	Please contact technical support.
Error 6	Current is under low limit	Please contact technical support.
Error 7	Current is over high limit	Measured current is over the maximum limit. Check if there is not short-circuit at the current loop. Check function of current transmitter.


I forgot the password for setup

Please reset device to factory defaults. Procedure is described at following point.

Factory defaults

This procedure restore device to factory settings including network parameters (IP address, Subnet mask, etc.). For factory-defaults follow these steps:

- disconnect the power supply, unscrew upper cover of the device case
- press factory-defaults button and connect the power
- keep button pressed for 10 sec




- close the device

Technical specifications

Information about technical specifications of the device.

Dimensions



Basic parameters

Supply voltage:

DC voltage from 9 V to 30 V

Consumption:

~ 1 W device without powering connected sensors

Protection:

IP30

Measuring interval:

1 sec, faster readings is available via ModbusTCP protocol, for more information please contact technical support

Accuracy:

± 0.1 %FS from 0 °C to +50 °C

± 0.3 %FS from -30 °C to +80 °C

Measuring range:

0 to 25 mA

Resolution:

1 uA

A/D converter resolution:

24bit sigma-delta

Input Impedance:

20 Ω

Maximum overload current:

30 mA

Current load for +U1 and +U2 terminals:

max. 40 mA each

terminals are connected to supply voltage via PTC thermistors (overload protection). Output voltage depends on actual current load, it is approximately about 1.2 V lower than supply voltage.

Communication port:

RJ45 connector – galvanically isolated from communication line, 10Base-T/100Base-TX Ethernet (Auto-Sensing)

Recommended Connector Cable:

for industrial use there is recommended Cat5e STP cable, in less demanding applications can be replaced by Cat5 cable, maximum cable length 100 m

Supported protocols:

TCP/IP, UDP/IP, ARP, ICMP, DHCP

HTTP, SMTP, SNMPv1, ModbusTCP, SNMP, XML, JSON, SOAPv1.1, Syslog

SMTP protocol:

SMTP authentication – AUTH LOGIN

Encryption (SSL/TLS/STARTTLS) is not supported

Supported web browsers:

Mozilla Firefox 87 and later, Google Chrome 89 and later, Microsoft Edge 89 and later. Device should be also compatible with other browsers. Functionality wasn't tested with other web browsers.

Recommended minimum screen resolution:

1024 x 768

Memory:

1000 values for each channel inside non-backup RAM memory

Case material:

ASA

Mounting the device:

With two holes at the bottom of the unit

Weight:

~ 150 g

EMC:

2014/30/EU, EN 61326-1

Operating terms

Temperature and humidity range:

-30 °C to +80 °C, 0 to 100 %RH (no condensation)

Working position:

arbitrary

End of operation



Disconnect the device and dispose it according to current legislation for dealing with electronic waste. Electronic devices must be professionally destroyed.

Technical support and service

Technical support and service is provided by distributor. Contact is included in warranty certificate.

Preventive maintenance

Make sure the cables are not damaged periodically. Recommended calibration interval is 2 years.