


## MX2201/MX2202 Mounting Boot (BOOT-MX2201-2202) Manual


### Installing the Logger in the Mounting Boot

1




Holding both the boot and the logger upside down, insert the logger mounting tab into the boot as shown

2




Insert the other logger mounting tab into the boot, making sure the logger is securely seated in the boot as shown

### Mounting the Logger in the Boot to a Pipe




Use two of the included zip ties to mount the logger in the boot to a small pipe as shown



Use one of the included zip ties to mount the logger in the boot to a large pipe as shown

24847-B MAN-BOOT-MX2201-2202

### Mounting the Logger in a Boot to a Flat Surface



Use two #8 screws (not included) to mount the logger in the boot to a flat surface. Do not overtighten the screws.



For detailed mounting and deployment guidelines, refer to the logger manual at [www.onsetcomp.com/resources/documentation/21536-mx2201-mx2202-manual](http://www.onsetcomp.com/resources/documentation/21536-mx2201-mx2202-manual) or scan the code above.